

⇒ **InfraWorks basics**

- Overview of the User Interface
- Collaboration
- Create models
- Work with models
- Work with point clouds
- Exchange Data with Autodesk Civil 3D
- Exchange Data with ESRI ARCGIS
- Import data
- Configure data
- Select Features
- Style Features
- Create Proposals
- Adding Features
- Modify or move Features
- Create subsets of Features
- Measure Distances, Areas
- Creating Themes
- Create and share presentations
- Export model data
- Application options
- Use Expressions
- Filter and select data
- Creating expressions
- Use scripts

⇒ **Roadway Design**

- Component Roads
- Edit road geometry
- Edit roadside grading
- Intersections
- Quantities
- Sight distance analysis
- Optimization
- Traffic simulation and animation
- Mobility simulation and animation



⇒ **Civil structure design**

- Bridge design
- Tunnel design
- Parametric civil structure models

⇒ **Drainage design**

- Watershed analysis
- Culverts
- Drainage network
- Flood simulation

⇒ **Make a project by InfraWorks**

Autodesk InfraWorks